

Safety instructions

Choose the location for the scooter stand also according to the following safety considerations:

The parked scooters, as well as the scooter stands themselves, must not obstruct any paths, especially escape routes, entrances and exits, roads or the like. Access and egress to and from the scooter stand must be unobstructed.

Where scooter stands are permanently mounted, the support material (wall or floor) must be suitable for mounting! Avoid consequential damage (e.g. damaged pipes or lines, broken out pieces of wall, cracked floor slabs) by proper planning!

Please read the installation instructions before installation.

The scooter stands are designed for the safe parking of pedal scooters, skateboards and/or bicycles of various designs.

We must expressly warn against any improper use!

Only assemble the scooter stands yourself if you have the necessary technical knowledge and have mastered the necessary skills to avoid any problems, damage and injuries resulting from assembly errors!

Observe the enclosed assembly instructions and these safety instructions!

We accept no liability for damage caused by incorrect or improper assembly or use, by a tradesman or customer.


Video-tutorial for mounting



<https://montage.rollerstop.com>

eSxBUBOD60

Assembly instructions
for one eS module with “iron”
floor stand




Contact

If you have any further questions or comments, we look forward to hearing from you!



Illustration Assembly



Description Assembly Pt. 1/2

Rollerstop scooter stands always consist of 2 elements: The module with the parking spaces (RS4, RS8, eS3, eS5, etc.) and the matching fastening elements (wall bracket, floor stud for screwing on or setting in concrete, bracket floor stud).

Mounting of a Rollerstop module from the eS series with a screw-on floor stand (item number eSxBUBOD60):

When mounting the module, make sure that the lettering on the closed locking bracket can be read correctly to avoid a module being mounted upside down by mistake.

Please observe the recommendations for the respective surface:

substrate	recommendation
Concrete	YES
Asphalt	YES*
Soil with foundation	YES**

* Installation on an asphalt base/cover with reservation: due to the softening of the material at high temperatures, the anchoring may become loose over time.

** The "iron" floor stand ground supports can be anchored with long nails or hooks in solid soil to prevent slipping. Due to the material, this anchoring may become loose over time.

"Iron" floor stands can be equipped with modules on one or both sides.

Description Assembly Pt. 2/2

1. The first step is to connect the mounting elements to the modules. To do this, the supplied mounting screws (M8 x 50) must be inserted from the front through the hole in the module and then through a hole on one side of the "iron" floor stand.
2. Then the washer is threaded onto the screw behind it and the nut is applied. This can now be screwed on loosely. Enough play remains for the module to be set up at right angles to the fastening elements.
3. Now the module can be brought into position and screwed to the floor (choose the appropriate dowels depending on the surface, in most cases Ø 10mm dowels are a good choice).
4. After that all nuts and screws are still tightened with a wrench (size 13) so far that they can not be loosened by hand.
5. Important: If two or more modules are to be mounted next to each other (in series), a minimum distance of 12 cm must be maintained between the modules.

Important: If two or more modules are to be mounted next to each other (in series), a minimum distance of 9 cm must be maintained between the modules.



